

Consisting of:

Filter Curves	1612.1
Weighting Network	1612.2
Level Adjustment	1612.3
Complete Adjustment	1612.4
Octave-Frequency Table	1612.5
Automatic Switching Device	1612.6
Position of Components	1612.7
Parts List	1612.8
Circuit Diagram	1612.9

Removal of the Metal Case.

After removing the four threaded retainers at the back of the instrument, it is possible to slide the chassis and the front panel out of the case.

Trouble Shooting.

If the reason for a fault is not an obvious one such as faulty transistor, broken down resistor, etc., then first test the voltages of the transistors and compare them with the voltages shown in the printed circuit (Position of components 1612.7) in order to localize the defect. Should this method of finding the fault prove unsuccessful, then check the instrument by adopting the method described in the adjustment procedure. To correct a fault in a filter the filter drawer in question must be taken out. This can be done after the leads to the drawer have been unsoldered and the two screws which hold the drawer in place removed. The drawer will be rather tight at beginning, as the other end is held firmly by a pair of springs. When the trouble has been found and remedied, the voltages and adjustments which are influenced by the remedy must be rechecked.

The tolerances stated in the instructions can only be used as a guide for adjustment and control, but any deviations must not be corrected without being sure that the tolerances of the instruments used for making the adjustment are so small as to have no influence on the measurements.

The instructions in this Manual are given purely as a guide to the service of equipment. Some faults, as f.inst. small deviations in tolerances require for their correction special control equipment and extensive experience, and in these cases it is necessary to send the instrument to the factory.



Spare Parts.

Please state type and serial number of apparatus when spare parts are ordered.

Instruments and accessories necessary for service and repair:


Multimeter (50 µA)
Frequency Analyzer type 2107
Beat Frequency Oscillator type 1022
(Beat Frequency Oscillator type 1013)
(Frequency Counter)
Pressure Gauge (30 - 50 gr)

1/3 Octave Filter





L101	↓ ↑ ↓ ↑ ↓ ↑	Change in filtercurve if the iron core or adjustmenttape are moved out of the coil
L102	↓ ↑ ↓ ↑ ↓ ↑	
L103	↑ ↓ ↑ ↓ ↑ ↓	
R101	↓ ↓ ↓ ↓ ↓ ↓	Change in filtercurve if the potentiometer is adjusted to a smaller resistance
R102	↓ ↓ ↓ ↓ ↓ ↓	
R103	↓ ↓ ↓ ↓ ↓ ↓	
R104	↓ ↓ ↓ ↓ ↓ ↓	
R105	↓ ↓ ↓ ↓ ↓ ↓	

Typical filtercurves for faulty filters



Faulty component	Adjustment procedure	Filtercurve for faulty filter
R 104,105	1612.3	+10 dB 0 dB -4 dB
R 101,102,103	1612.4	+4 dB 0 dB
C101, L101	1612.4	0 dB -5 dB
C103, L103	1612.4	0 dB -15 dB
L101,102,103 trimmer 'C'	1612.4	+2 dB 0 dB



2.1. Linear

- a. INPUT SWITCH: "Direct"
WEIGHTING NETWORK: "On"
FILTER SWITCH: "Lin."
FUNC.SELECTOR:"1/3 Octave"

Frequency: 1000 c/s. Adjust the input voltage for an 18 dB deflection on type 2107 (RANGE MULT.: "x1" and WEIGHTING NETWORK: "Lin. 2-40000 c/s")

Change WEIGHTING NETWORK on type 2107 to "Ext. Filter".

Change frequency to 50 c/s.

Deflection on type 2107: 17.7 - 18.2 dB.

If necessary adjust R 99 "Lin. 1/3"

Possible reasons for fault: defective transistor V1, V2
defective zener diode Q1.

d.c. voltage for transistor amplifier: Q1: approx. 12 V

V2 emitter: approx. 5 V

base: approx. 4.8 V.

Vary the frequency from 20-20000 c/s.

Deflection on type 2107: 18 dB

Tolerance: + 0.3 dB (+ tolerance of type 1022: 0.3 dB and type 2107: 0.2 dB)

- b. FUNC.SELECTOR to
"1/1 Octave"

Vary the frequency from 20 - 20000 c/s.

Deflection on type 2107: 18 dB (RANGE MULT.: "x 0.3").

Tolerance: + 0.6 dB (+ tolerance of type 1022: 0.3 dB and type 2107: 0.2 dB)
If necessary change value of C 91 or R 88.

2.2. A-B-C Curves

- a. INPUT SWITCH: "Direct"
WEIGHTING NETWORK: "On"
FILTER SWITCH: "Lin."
FUNC.SELECTOR:"1/3 Octave"

Frequency: 1000 c/s. Adjust the input voltage for an 18 dB deflection on type 2107 (RANGE MULT.: "x1" and WEIGHTING NETWORK: "Lin. 2-40000 c/s")

Change WEIGHTING NETWORK on type 2107 to "Ext. Filter".

Deflection on type 2107: 17.7 - 18.3 dB.

If necessary adjust R 98 "A".

Deflection on type 2107: 17.7 - 18.3 dB.

If necessary adjust R 97 "B".

Deflection on type 2107: 17.7 - 18.3 dB.

If necessary adjust R 94 "C".

Whenever R 94, 97, 98 is adjusted item e should be checked as the settings of these potentiometers influence each other.


e.

Curve "A"


Curve "B"

Curve "C"

Frequency c/s	Defl. on type 2107 dB	RANGE MULT.	Defl. on type 2107 dB	RANGE MULT.	Defl. on type 2107 dB	RANGE MULT.
20	4.6 - 12.6	X 0.01	10.6 - 18.6	X 0.1	8.7 - 16.7	X 1
63	10.4 - 13.9	X 0.1	7.1 - 10.6	X 1	15.7 - 19.2	X 1
500	14.4 - 15.2	X 1	17.3 - 18.1	X 1	17.6 - 18.4	X 1
1000	17.7 - 18.3	X 1	17.7 - 18.3	X 1	17.7 - 18.3	X 1
2000	19.0 - 19.4	X 1	17.6 - 18.0	X 1	17.6 - 18.0	X 1
8000	15.7 - 17.4	X 1	13.8 - 15.5	X 1	13.8 - 15.5	X 1
20000	6.8 - 10.3	X 1	15.0 - 18.5	X 0.3	14.9 - 18.4	X 0.3



8 kHz 6.3 kHz 25 kHz
10 kHz 16 kHz 31.5 kHz
12.5 kHz 20 kHz 40 kHz



3.1. 1/3 Octave Filter

- a. INPUT SWITCH: "Direct".
FUNC. SELECTOR: "1/3 Octave".
WEIGHTING NETWORK: "On"

Set the frequency to the center frequency of the filter and adjust the input voltage for an 18 dB deflection on type 2107 (RANGE MULT.: "X1" and WEIGHTING NETWORK: "Lin. 2-40000 c/s").

Change WEIGHTING NETWORK on type 2107 to "Ext. Filter".

Vary the frequency around the center frequency of the filter and check the filter curve.

Deflection on type 2107: 18.0 - 18.5 dB for the tops
17.5 - 18.0 dB for the valleys

If necessary adjust R104 or R105.

Change frequency to + and - 1/6 octave.

Deflection on type 2107: approx. 15 dB.

After adjustment of R104-105, check 3.2

As under item b but adjust the valleys by means of R104 or R105 and the tops by means of trimmer "C".

Check of these filters requires use of a high frequency oscillator f.inst. type 1013.

Check and tolerances as under item c.

3.2. 1/1 Octave Filter

- a. INPUT SWITCH: "Direct"
FUNC. SELECTOR: "1/1 Octave"
WEIGHTING NETWORK: "On"

Set frequency to the center frequency of the filter and adjust the input voltage for an 18 dB deflection on type 2107 (RANGE MULT.: "X1" and WEIGHTING NETWORK :! Lin. 2-40000 c/s)

Change WEIGHTING NETWORK on type 2107 to "Ext.Filter" and RANGE MULT. to "Xo.3".

Vary the frequency around the center frequency of the filter.

Deflection on type 2107: 18 - 20 dB for the tops
16 - 18 dB for the valleys

Change frequency to + and - 1/2 octave.

Deflection on type 2107: approx. 15 dB

If necessary to adjust the filter. Set the frequency at the point where the deflection exceeds the tolerance and note the deviation from 18 dB deflection on type 2107.

Change FUNC.SELECTOR to "1/3 Octave" and turn the FILTER SWITCH to the defect 1/3 octave filter, indicated by the greatest deflection on type 2107 (RANGE MULT.: "X1")

Change frequency to the center frequency of the defect filter and adjust the deflection on type 2107 by means of R104 to the deviation just noted from 18 dB deflection, but in opposite direction.

Then adjust R105 for a deflection on type 2107: 17.5-18.0 dB and repeat item b.

Adjustment as under item b,
but deflection on type 2107: 18 - 19 dB for the tops
17 - 18 dB for the valleys.

Adjustment of these filters requires use of a high frequency oscillator f.inst. type 1013.


Adjustment and tolerances as under item c.

- b. FILTER SWITCH in required position
31.5 - 63 c/s

- c. FILTER SWITCH in required position
125-8000 c/s

- d. FILTER SWITCH in required position
16000 - 31000 c/s

valid from serial no. 64072



MODULATION: "Off"

COMPRESSOR: "Off"

MATCHING IMP.: "6Ω"

INPUT SWITCH: "Direct"

WEIGHTING NETWORK: "Lin 2-4000"

METER SWITCH: "RMS, fast"

FUNC. SELECTOR: "Selec. Section Off"

Before adjustment turn potentiometer R101-2-3 to mid. position R104 to max. resistance and R105 to min. resistance.

4.1. Adjustment of Resonant Circuit I and II

a. Reference adj.

Connect: S and V to point I
b to point G

Set the frequency to the center frequency of the filter and adjust the input voltage for an 18 dB deflection on type 2107 (RANGE MULT.: "x1" and METER RANGE: "1 V").

b. Adj. of resonant frequency L101.

Change V to point a.

Change frequency to approx. 1% above the center frequency of the filter and adjust L101 to max. deflection on type 2107.

c. Adj. of Q. R101.

Adjust R101, if any (some of the low frequency filters have no R101), for a 19 dB deflection on type 2107 (RANGE MULT.: "x1" and METER RANGE: "10 V")


d. Adj. of resonant frequency L102.

Connect: S to point a.
V to point b.
Filter output to point G.

Adjust L102 to max. deflection on type 2107 at the same frequency as under item b.

e. Adj. of Q. R102

Adjust R102, if any (some of the low frequency filters have no R102), for a 10 dB deflection on type 2107 (RANGE MULT.: "x0.3" and METER RANGE: "10 V".)




4.2. Adjustment of Resonant Circuit III

a. Reference Adj.

Connect: S to V.

Set the frequency to the center frequency of the filter and adjust the input voltage for an 18 dB deflection on type 2107 (RANGE MULT.: "x1" and METER RANGE: "1 V").

- octave			center frequency c/s	+ octave		
1/2	1/3	1/6		1/6	1/3	1/2
11.22	10.00	11.22	12.5	14.13	15.85	
	12.59	14.13	16	17.78	19.95	
	15.85	17.78	20	22.40	25.10	22.40
22.40	19.95	22.40	25	28.20	31.60	
	25.10	28.20	31.5	35.50	39.80	44.70
	31.60	35.50	40	44.70	50.10	
44.70	39.80	44.70	50	56.20	63.10	
	50.10	56.20	63	70.80	79.40	89.10
	63.10	70.80	80	89.10	100.0	
89.10	79.40	89.10	100	112.2	125.9	
	100.0	112.2	125	141.3	158.5	177.8
	125.9	141.3	160	177.8	199.5	
177.0	158.5	177.8	200	224.0	251.0	
	199.5	224.0	250	282.0	316.0	355.0
	251.0	282.0	315	355.0	398.0	
355.0	316.0	355.0	400	447.0	501.0	
	398.0	447.0	500	562.0	631.0	708.0
	501.0	562.0	630	708.0	794.0	
708.0	631.0	708.0	800	891.0	1000	
	794.0	891.0	1000	1122	1259	1413
	1000	1122	1250	1413	1585	
1413	1259	1413	1600	1778	1995	
	1585	1778	2000	2240	2510	2820
	1995	2240	2500	2820	3160	
2820	2510	2820	3150	3550	3980	
	3160	3550	4000	4470	5010	5620
	3980	4470	5000	5620	6310	
5620	5010	5620	6300	7080	7940	
	6310	7080	8000	8910	10000	11220
	7940	8910	10000	11220	12590	
11220	10000	11220	12500	14130	15850	
	12590	14130	16000	17780	19950	22400
	15850	17780	20000	22400	25100	
22400	19950	22400	25000	28200	31600	
	25100	28200	31500	35500	39800	44700
	31600	35500	40000	44700	50100	



6.1. Mechanical Adjustment

a. Max. operating power

Operate the FILTER SWITCH automatically, by means of pulses from a Level Recorder Type 2305 or an external DC supply (24 V, 180 mA) in series with a switch, connected to REMOTE CONTROL jack. (+ should be connected to pin 2 and - to pin 1).

Loosen screw A and rotate the motor until max. operating power is obtained.

Before retightening screw A check that the pawl B is located in the middle of the pawl wheel C.

b. Pawl mechanism

Turn the motor axle D clockwise to its limit. Check that the spring loaded locking roll E is in a position between 2 teeth on the pawl wheel C. If not loosen the nut and turn the eccentric nylon bush F to the correct position. After adjustment carefully retighten the nut.

Turn the motor axle D slowly clockwise and check the movement of the pawl B. The pawl should first move down to the pawl wheel C on a point between 2 teeth and then turn the pawl wheel one position. If not, loosen the nut and turn the eccentric nylon bush G to the correct position. After adjustment carefully retighten the nut.

Replace the frequency pointer and the bakelite knob.

Adjust the spring load on locking roll E by means of screw H. The movement of the FILTER SWITCH should be smooth but the screw should be tightened so that the pressure can overcome the friction in the switch and move the pawl wheel back again if it is left a little out of locking position.

Operate the FILTER SWITCH automatically as under item a and check that the switching is stable, if not readjust screw H.

c. Play in the frequency pointer.

Loosen screw I and tighten it again in a position where the play between the nylon wheel K and both the metal wheels L and M is small, but without any point where the wheels are moved with force.

d. Lubricating

Apply a little thin non-acidic machine oil (e.g. sewing machine oil) only to the following parts: Motor, point N

Switching axle, point Q

Pawl mechanism, point O, P

6.2. 50 Position Switch

a. Cleaning

Remove the protecting tape from the left side of the switch.

Loosen screws R-S-T-U and pull out axle V far enough so that the rotary contacts X-Y are free.

Carefully clean the fixed and rotary contacts with a soft cloth and trichlor-ethylene.

b. Contact Pressure

After cleaning replace the rotary contacts X-Y and axle V, tighten the pawl wheel C and stop-bush Z in a position which allows only a slight play in the axial direction.

Adjust the rotary contacts X-Y along the axle for a contact pressure of 30-40 gr. and tighten screws T-U.

c. Check of Switch

Connect an ohmmeter across the core in the coax cable "Lin.1/3" and the green lead connected to soldering tag "Lin. 1/3" on filter drawer ZS 0150 and turn the FILTER SWITCH to a position where the resistance is 0.


Replace the frequency scale and fix the pointer in position "Lin."

Check that the rotary contact Y is placed on the axle V in relation to the pawl wheel so that it gives contact symmetrically around the locking position. If not loosen screw U and correct the position of the rotary contact.

After adjustment recheck contact pressure.




Connect the ohmmeter across the core in the coax cable "Lin.0" and the red lead connected to soldering tag "Lin.0" on filter drawer ZS 0150. Set the FILTER SWITCH to "Lin."

Check the rotary contact X in the same way as rotary contact Y.



Lin 1/1 - 1/3 octave

Weighting Network
curve A-B-C





Position of Components

valid from serial no. 139535

1612.7

Sheet 2.





Parts-List

valid from serial no. 171746

COMPONENT TYPE	STOCK REFERENCE	CIRCUIT DIAGRAM	COMPONENT TYPE	STOCK REFERENCE	CIRCUIT DIAGRAM
CAPACITORS:					
Electrolytic	40 $\mu\text{F}/170 \text{ V}$	CE 2038	C 1	Polystyrene	3.16 nF $\pm 2\% / 200 \text{ V}$
"	25 $\mu\text{F}/50 \text{ V}$	CE 8948	C 2	"	4 nF $\pm 2\% / 200 \text{ V}$
"	10 $\mu\text{F}/15 \text{ V}$	CE 0001	C 3	"	6.3 nF $\pm 2\% / 200 \text{ V}$
Polyester	0.1 $\mu\text{F}/250 \text{ V}$	CS 0013	C 5	"	63 nF $\pm 2\% / 100 \text{ V}$
"	0.47 $\mu\text{F}/250 \text{ V}$	CS 0021	C 4	Auto-transformer	
SWITCHES:					
Input switch	NN 0564	O 1	Coil	50 H	LB 0017
Weighting Network	NN 0567	O 5	Trimmer pot.m.	150 k Ω lin.	PG 4151
Function Selector	OR 1611	O 2	"	1 MO lin.	PG 5102
Automatic switching	OX 1016	O 4	Carbon film	1/3 W $\pm 5\%$	RK 400 Ω
RESISTORS:					
Carbon film	1/3 W $\pm 10\%$	RK 250 Ω	R 107	"	R 89
"	" "	RK 1 k Ω	R 9	"	R 90,91
"	" "	RK 12.5 k Ω	R 1	"	R 92
"	" "	RK 25 k Ω	R 2	"	R 93
"	" "	RK 50 k Ω	R 3	"	R 95,96
"	" "	RK 100 k Ω	R 4		
"	" "	RK 200 k Ω	R 5		
"	" "	RK 370 k Ω	R 7		
"	" "	RK 430 k Ω	R 6		
"	" "	RK 2 M Ω	R 8		
"	1/2 W $\pm 10\%$	RK 425 k Ω	R 117-120		
RECTIFIERS:					
Zener diode	12 V $\pm 10\%$	QV 1117	Q 1	1/3 OCTAVE FILTERS:	
Germanium diode	OA 85	QV 0085	Q 2,3,13	FILTER 12.5 c/s:	
TRANSISTORS:					
Transistor	2N2374	VB 1022	V 1	Polyester	1 $\mu\text{F} \pm 10\% / 250\text{V}$
"	"	VB 2022	V 2	Trimmer pot.m.	300 k Ω lin.
PRINTED CIRCUITS:				"	PG 4300
Emitter follower	XC 0204			"	250 k Ω lin.
Weighting network	XC 0036			Coil	80 H
Filter	XC 0203			"	LB 0504
"	XC 0008				L 102,103
"	XC 0035				LB 0505
"	XC 0058				L 101
XC 0204 with components	1612 bl. 801				
XC 0203 " "	1612 bl. 800				
MISCELLANEOUS:					
Cable for battery (1612)	AQ 0008			FILTER 16 c/s:	
Cable for remote control (2305)	AQ 0002			Polyester	1 $\mu\text{F} \pm 10\% / 250\text{V}$
Rubber foot	DF 2010			"	0.68 $\mu\text{F} \pm 10\% / 250\text{V}$
Coaxial jack	JJ 0115			Trimmer pot.m.	300 k Ω
7-pole jack	JJ 0018			"	250 k Ω lin.
6-pole jack	JJ 4704			Coil	50 H
Coaxial plug	JP 0018			"	LB 0501
Mechanical adaptor	JP 0019				L 102,103
Ground jack	JT 6204				LB 0500
Case, wood	KA 0012				L 102,103
Case, metal	KQ 0010				
Frequency dial	SA 0206				
Bakelite knob 30 Ø	SN 0814				
" 54 Ø	SN 3810				
" 30 Ø twin marking	SN 0816				
Pointer for frequency dial	SV 0015				
Housing for freq. Scale	SO 0188				
Auto-transformer	TQ 0003	T			
Motor for automatic switching	UM 0006				
Aut. Switching device	OC 0310	O 3			
WEIGHTING NETWORK:					
Electrolytic	40 $\mu\text{F}/50 \text{ V}$	CE 2038	C 89	FILTER 20 c/s:	
"	2 $\mu\text{F}/50 \text{ V}$	CE 2648	C 99	Polyester	1 $\mu\text{F} \pm 10\% / 250\text{V}$
Ceramic	5 pF/500 V	CK 0034	C 90	"	0.22 $\mu\text{F} \pm 10\% / 250\text{V}$
1/3 OCTAVE FILTERS:					
FILTER 12.5 c/s:					
FILTER 16 c/s:					
FILTER 20 c/s:					
FILTER 25 c/s:					
FILTER 31.5 c/s:					
FILTER 35 c/s:					
FILTER 40 c/s:					
FILTER 50 c/s:					

COMPONENT TYPE	STOCK REFERENCE	CIRCUIT DIAGRAM	COMPONENT	STOCK REFERENCE	CIRCUIT DIAGRAM
<u>FILTER 63 c/s:</u>					
Polystyrene 400 nF [±] 5%/100 V	CT 6104	C 101-103	FILTER 400 c/s:	Polystyrene 63 nF [±] 5%/100 V	CT 3431 C 101-103
Trimmer pot.m. 150 kΩ lin.	PG 4151	R 105	Trimmer pot.m.	500 kΩ lin.	PG 4502 R 101
" 300 kΩ lin.	PG 4301	R 104	"	300 kΩ lin.	PG 4301 R 103, 104
Coil 16 H	LB 0412	L 102,103	Coil	150 kΩ lin.	PG 4151 R 105
" 16 H	LB 0413	L 101	"	2.5 H	LB 0419 L 102,103
			"	2.5 H	LB 0420 L 101
<u>FILTER 80 c/s:</u>					
Polystyrene 320 nF [±] 5%/100 V	CT 6105	C 101-103	FILTER 500 c/s:	Polystyrene 50 nF [±] 5%/100 V	CT 3430 C 101-103
Trimmer pot.m. 150 kΩ lin.	PG 4151	R 105	Trimmer pot.m.	500 kΩ lin.	PG 4502 R 101
" 300 kΩ lin.	PG 4301	R 104	"	300 kΩ lin.	PG 4301 R 103, 104
Coil 12.5 H	LB 0414	L 102,103	Coil	150 kΩ lin.	PG 4151 R 105
" 12.5 H	LB 0415	L 101	"	2 H	LB 0421 L 102,103
			"	2 H	LB 0422 L 101
<u>FILTER 100 c/s:</u>					
Polystyrene 250 nF [±] 5%/100 V	CT 6102	C 101-103	FILTER 630 c/s:	Polystyrene 40 nF [±] 5%/100 V	CT 3239 C 101-103
Trimmer pot.m. 150 kΩ lin.	PG 4151	R 105	Trimmer pot.m.	1 MΩ lin.	PG 5102 R 101
" 300 kΩ lin.	PG 4300	R 103	"	300 kΩ lin.	PG 4301 R 103, 104
" 300 kΩ lin.	PG 4301	R 104	"	150 kΩ lin.	PG 4151 R 105
Coil 10 H	LB 0116	L 102,103	Coil	1.6 H	LB 0423 L 102,103
" 10 H	LB 0117	L 101	"	1.6 H	LB 0424 L 101
<u>FILTER 125 c/s:</u>					
Polystyrene 200 nF [±] 5%/100 V	CT 6103	C 101-103	FILTER 800 c/s:	Polystyrene 31.5 nF [±] 5%/100 V	CT 3238 C 101-103
Trimmer pot.m. 150 kΩ lin.	PG 4151	R 105	Trimmer pot.m.	1 MΩ lin.	PG 5102 R 101
" 300 kΩ lin.	PG 4300	R 103	"	300 kΩ lin.	PG 4301 R 103, 104
" 300 kΩ lin.	PG 4301	R 104	"	150 kΩ lin.	PG 4151 R 105
Coil 8 H	LB 0118	L 102,103	Coil	1.25 H	LB 0425 L 102,103
" 8 H	LB 0119	L 101	"	1.25 H	LB 0426 L 101
<u>FILTER 160 c/s:</u>					
Polystyrene 160 nF [±] 5%/100 V	CT 6101	C 101-103	FILTER 1 k c/s:	Polystyrene 25 nF [±] 5%/100 V	CT 3237 C 101-103
Trimmer pot.m. 150 kΩ lin.	PG 4151	R 105	Trimmer pot.m.	300 kΩ lin.	PG 4301 R 101, 104
" 300 kΩ lin.	PG 4300	R 103	"	500 kΩ lin.	PG 4502 R 102
" 300 kΩ lin.	PG 4301	R 104	"	150 kΩ lin.	PG 4151 R 103, 105
Coil 6.3 H	LB 0120	L 102,103	Coil	1 H	LB 0440 L 102,103
" 6.3 H	LB 0121	L 101	"	1 H	LB 0441 L 101
<u>FILTER 200 c/s:</u>					
Polystyrene 125 nF [±] 5%/100 V	CT 6100	C 101-103	FILTER 1.25 k c/s:	Polystyrene 20 nF [±] 5%/200 V	CT 3230 C 101-103
Trimmer pot.m. 800 kΩ lin.	PG 5101	R 101	Trimmer pot.m.	300 kΩ lin.	PG 4301 R 101, 104
" 300 kΩ lin.	PG 4300	R 103	"	500 kΩ lin.	PG 4502 R 102
" 300 kΩ lin.	PG 4301	R 104	"	150 kΩ lin.	PG 4151 R 103, 105
" 150 kΩ lin.	PG 4151	R 105	Coil	800 mH	LB 0442 L 102,103
Coil 5 H	LB 0122	L 102,103	"	800 mH	LB 0443 L 101
" 5 H	LB 0123	L 101			
<u>FILTER 250 c/s:</u>					
Polystyrene 100 nF [±] 5%/100 V	CT 3433	C 101-103	FILTER 1.6 k c/s:	Polystyrene 16 nF [±] 5%/100 V	CT 3236 C 101-103
Trimmer pot.m. 300 kΩ lin.	PG 4301	R 103,104	Trimmer pot.m.	300 kΩ lin.	PG 4301 R 101, 104
" 150 kΩ lin.	PG 4151	R 105	"	500 kΩ lin.	PG 4502 R 102
Coil 4 H	LB 0429	L 102,103	"	150 kΩ lin.	PG 4151 R 103, 105
" 4 H	LB 0430	L 101	Coil	640 mH	LB 0444 L 102,103
			"	640 mH	LB 0445 L 101
<u>FILTER 315 c/s:</u>					
Polystyrene 80 nF [±] 5%/100 V	CT 3432	C 101-103	FILTER 2 k c/s:	Polystyrene 12.5 nF [±] 5%/200 V	CT 3235 C 101-103
Trimmer pot.m. 300 kΩ lin.	PG 4301	R 103,104	Trimmer pot.m.	300 kΩ lin.	PG 4301 R 101, 104
" 150 kΩ lin.	PG 4151	R 105	"	500 kΩ lin.	PG 4502 R 102
Coil 3.16 H	LB 0427	L 102,103	"	150 kΩ lin.	PG 4151 R 103, 105
" 3.16 H	LB 0428	L 101	Coil	500 mH	LB 0446 L 102,103
			"	500 mH	LB 0447 L 101

valid from serial no. 139535


Sheet 2.

COMPONENT TYPE	STOCK REFERENCE	CIRCUIT DIAGRAM	COMPONENT TYPE	STOCK REFERENCE	CIRCUIT DIAGRAM
<u>FILTER 2.5 k c/s:</u>					
Polystyrene 10 nF ⁺ 5%/200 V	CT 3228	C 101-103	Polystyrene 2 nF ⁺ 5%/400 V	CT 3222	C 101-103
Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104	Trimmer, ceramic 10-40 pF/250 V	CV 0019	"C"
" 500 kΩ lin.	PG 4502	R 102	Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104
" 150 kΩ lin.	PG 4151	R 103,105	" 500 kΩ lin.	PG 4502	R 102
Coil 400 mH	LB 0432	L 102,103	" 150 kΩ lin.	PG 4151	R 103,105
" 400 mH	LB 0433	L 101	Coil 71.5 mH	LB 0532	L 102,103
" 71.5 mH	LB 0533	L 101	" 71.5 mH	LB 0533	L 101
<u>FILTER 3.15 k c/s:</u>					
Polystyrene 8 nF ⁺ 5%/200 V	CT 3227	C 101-103	Polystyrene 1.6 nF ⁺ 5%/400 V	CT 3232	C 101-103
Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104	Trimmer, ceramic 10-40pF/250 V	CV 0019	"C"
" 500 kΩ lin.	PG 4502	R 102	Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104
" 150 kΩ lin.	PG 4151	R 103,105	" 500 kΩ lin.	PG 4502	R 102
Coil 320 mH	LB 0434	L 102,103	" 150 kΩ lin.	PG 4151	R 103,105
" 320 mH	LB 0435	L 101	Coil 56.8 mH	LB 0534	L 103
" 55.5 mH	LB 0535	L 102	" 45.1 mH	LB 0537	L 103
<u>FILTER 4 k c/s:</u>					
Polystyrene 6.3 nF ⁺ 5%/200 V	CT 3234	C 101-103	Polystyrene 1.25 nF ⁺ 5%/400 V	CT 3219	C 101-103
Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104	Trimmer, ceramic 10-40pF/250 V	CV 0019	"C"
" 500 kΩ lin.	PG 4502	R 102	Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104
" 150 kΩ lin.	PG 4151	R 103,105	" 500 kΩ lin.	PG 4502	R 102
Coil 250 mH	LB 0436	L 102,103	" 150 kΩ lin.	PG 4151	R 103,105
" 250 mH	LB 0437	L 101	Coil 45.1 mH	LB 0538	L 102
" 44.1 mH	LB 0538	L 102	" 45.1 mH	LB 0539	L 101
<u>FILTER 5 k c/s:</u>					
Polystyrene 5 nF ⁺ 5%/200 V	CT 3226	C 101-103	Polystyrene 1 nF ⁺ 5%/500 V	CT 0118	C 101-103
Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104	Trimmer, ceramic 10-40pF/250 V	CV 0019	"C"
" 500 kΩ lin.	PG 4502	R 102	Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104
" 150 kΩ lin.	PG 4151	R 103,105	" 500 kΩ lin.	PG 4502	R 102
Coil 200 mH	LB 0438	L 102,103	" 150 kΩ lin.	PG 4151	R 103,105
" 200 mH	LB 0439	L 101	Coil 35.8 mH	LB 0540	L 103
" 34.8 mH	LB 0541	L 102	" 35.8 mH	LB 0542	L 101
<u>FILTER 6.3 k c/s:</u>					
Polystyrene 4 nF ⁺ 5%/200 V	CT 3225	C 101-103	Polystyrene 0.8 nF ⁺ 5%/500 V	CT 0116	C 101-103
Trimmer, ceramic 10-40 pF/250 V	CV 0019	"C"	Trimmer, ceramic 10-40pF/250 V	CV 0019	"C"
Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104	Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104
" 500 kΩ lin.	PG 4502	R 102	" 500 kΩ lin.	PG 4502	R 102
" 150 kΩ lin.	PG 4151	R 103,105	" 150 kΩ lin.	PG 4151	R 103,105
Coil 144 mH	LB 0526	L 102,103	Coil 28.5 mH	LB 0543	L 103
" 144 mH	LB 0527	L 101	" 27.8 mH	LB 0544	L 102
" 28.5 mH	LB 0545	L 101	" 28.5 mH	LB 0545	L 101
<u>FILTER 8 k c/s:</u>					
Polystyrene 3.2 nF ⁺ 5%/200 V	CT 3233	C 101-103	Polystyrene 0.8 nF ⁺ 5%/500 V	CT 0116	C 101-103
Trimmer, ceramic 10-40 pF/250 V	CV 0019	"C"	Trimmer, ceramic 10-40pF/250 V	CV 0019	"C"
Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104	Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104
" 500 kΩ lin.	PG 4502	R 102	" 500 kΩ lin.	PG 4502	R 102
" 150 kΩ lin.	PG 4151	R 103,105	" 150 kΩ lin.	PG 4151	R 103,105
Coil 113 mH	LB 0528	L 102,103	Coil 28.5 mH	LB 0543	L 103
" 113 mH	LB 0529	L 101	" 27.8 mH	LB 0544	L 102
" 28.5 mH	LB 0545	L 101	" 28.5 mH	LB 0545	L 101
<u>FILTER 10 k c/s:</u>					
Polystyrene 2.5 nF ⁺ 5%/400 V	CT 3223	C 101-103	Polystyrene 0.63 nF ⁺ 5%/400 V	CT 3214	C 101-103
Trimmer, ceramic 10-40 pF/250 V	CV 0019	"C"	Trimmer, ceramic 10-40pF/250 V	CV 0019	"C"
Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104	Trimmer pot.m. 300 kΩ lin.	PG 4301	R 101,104
" 500 kΩ lin.	PG 4502	R 102	" 500 kΩ lin.	PG 4502	R 102
" 150 kΩ lin.	PG 4151	R 103,105	" 150 kΩ lin.	PG 4151	R 103,105
Coil 90 mH	LB 0530	L 102,103	Coil 22.6 mH	LB 0546	L 103
" 90 mH	LB 0531	L 101	" 21.6 mH	LB 0547	L 102
" 22.6 mH	LB 0548	L 101	" 22.6 mH	LB 0548	L 101

1612.s

valid from serial no. 130631

Filter No.	Frequency c/s	L 101, 102 and 103 H	C 101– 103 nF	R 101 k Ω	R 102 k Ω	R 103 k Ω	R 104 k Ω	R 105 k Ω
ZS 0146	12,5	80	2000				250	300
	16	63	1600				"	"
	20	50	1250				"	"
ZS 0048	25	40	1000				300	"
ZS 0049	31,5	31,5	800				"	"
ZS 0029	40	25	630				"	"
	50	20	500				"	"
ZS 0030	63	16	400				"	150
	80	12,5	315				"	"
ZS 0031	100	10	250			300	"	"
	125	8	200			"	"	"
ZS 0032	160	6,3	160			"	"	"
	200	5	125 (800)			"	"	"
ZS 0150	250	4	100			"	"	"
	315	3,15	80			"	"	"
ZS 0151	400	2,5	63 1000			"	"	"
	500	2	50 500			"	"	"
	630	1,6	40 1000			"	"	"
	800	1,25	31,5 500			"	"	"
ZS 0152	1000	1,0	25 500		150	"	"	"
	1250	0,8	20 300	500	"	"	"	"
	1600	0,63	16 "	"	"	"	"	"
	2000	0,5	12,5 "	"	"	"	"	"
ZS 0153	2500	0,4	10 "	"	"	"	"	"
	3150	0,315	8 "	"	"	"	"	"
	4000	0,25	6,3 "	"	"	"	"	"
	5000	0,2	5 "	"	"	"	"	"
ZS 0039	6300	0,16	4 "	"	"	"	"	"
	8000	0,125	3,15 "	"	"	"	"	"
	10000	0,1	2,5 "	"	"	"	"	"
	12500	0,08	2 "	"	"	"	"	"
	16000	0,063	1,6 "	"	"	"	"	"
	20000	0,05	1,25 150	"	"	"	"	"
ZS 0142	25000	0,04	1,0 "	"	"	"	"	"
	31500	0,0315	0,8 "	"	"	"	"	"
	40000	0,025	0,63 "	"	"	"	"	"



01: Input Sw

- 1: Direct
- 2: Transformer

02: Function Sets

1: 1/3 Octave
2: Octave

03: Filter Sys

1-3: Extension

04: Autom

1: Off

3. Switching 05: Weighting

C. Switching D. Weighting

25 - 5 - 61	64 072	9 - 9 - 64	130631	Brüel & Kjær Copenhagen		Band-pass Filter Set Type 1612
5 - 12 - 61	77518					
17 - 5 - 63	107296					

Brüel & Kjaer
Copenhagen



**Band-pass Filter Set
Type 1612**